

PRODUCT NAME	KNOBS FIT	FADERS FIT
Native Instruments Kontrol S4	Yes	Yes
Native Instruments Kontrol S2	Yes	Yes
Native Instruments Kontrol X1	Yes	Yes
Native Instruments Maschine	Yes ^{^^}	N/A
Vestax VCI-100 Mk1	Yes	Yes
Vestax VCI-100 Mk2	Yes ^{**}	Yes
Vestax VCI-300	Yes ^{**}	Yes
Vestax Typhoon/Spin	Yes	Yes
Vestax VCM-600	Yes	Yes
Rane 68	Yes ^{^^}	Yes (xx)
Rane TTM-57	Yes	No
Novation Twitch	Yes ^{^^}	Yes
Numark NS6	Yes	Yes
Numark NS7	Yes	Yes
Numark V7	Yes	Yes
Numark Total Control	Yes ^{^^}	Yes ^{^^}
Numark Mixdeck	Yes	Yes ^{**}
Numark Mixtrack/Mixtrack Pro	Yes	Yes
Numark DJ2G0	Yes	No
Akai APC20	Yes ^{^^}	No (><)
Akai APC40	Yes ^{^^}	No (><)
Akai MPD 26/32	Yes ^{^^}	Yes
Pioneer DDJ-T1	No	No
Pioneer DJM-400,DJM-2000	No	No
Xone DX	No	Yes
Denon DN-MC6000	No	Yes
Denon DN-X120	Yes	Yes
Denon DN-X1600	No	Yes ^{^^}
Denon DN-HC5000	Yes ^{^^}	Yes ^{^^}
Denon X1500	Yes ^{**}	Yes
M-Audio Trigger Finger	Yes ^{^^}	No
M-Audio Oxygen 8	Yes	Yes
American Audio VMS4	No	Yes
Stanton SCS.4DJ	Yes	Yes
Reloop Jockey 2	Yes	Yes
Mixvibes U-Mix Control Pro	Yes ^{^^}	Yes ^{**}
Faderfox DJ3	No	Yes
Faderfox DL3	No	N/A
Faderfox FT3	No	No (><)
Korg Nano Kontrol	No	No
Korg Kaoss Pad KP3	No	No
Korg KM-402	Yes	No
Korg KM-202	Yes	No
Korg Zero4	Yes	No
Korg Zero8	Yes	No
Behringer DDM-4000	No	No
Behringer DJX750	No	No
Hercules dj console 4-mx	Yes	Yes
Hercules dj console Mk4	Yes ^{^^}	Yes ^{^^}
Innofader	N/A	No
DJ Tech xIO	No	Yes

^{^^} = Knobs/Faders sit high on controller

^{**} = Knobs/Faders bottom out on surface of controller (fixable)

>< = Fader caps fit on but are too close together and interfere

xx = Fader caps fit on level faders but not on Crossfader